



Step 1. Position Barkers at specified locations per the Barker installation diagram

Step 2. Turn on Barkers by moving the switch on Barker away from Barker centerline.

Barker LED will glow green when Barker is turned on.

Step 3. Position ThermoBlade next to GateWay

Step 4. Finish network initialization and start the test

Step 5. Confirm that DataLink displays real time data from ThermoBlade

Step 6. Position ThermoBlade at the entry of Tunnel Oven, not on the belt yet, and verify data acquisition

Step 7. If data acquisition goes well, let ThermoBlade go through the oven.

Otherwise, go back to Step 3.

Step 8. Once ThermoBlade exits the other end of the Tunnel Oven, position ThermoBlade next to GateWay

Step 9. Initiate [StopTest] command and wait for DataLink to finish collecting data from ThermoBlade.

DataLink closes the data window when the data collection is complete.